

### WaterTribe Rudder Installation Kit

SKU	Name	Quantity	Unit Price	Price	
10001	Gudgeon	2	\$25.00	\$50.00	Imported
20001	Pivot Pin	1	\$25.00	\$25.00	Manufactured by hand, not perfect but will do.
30001	#10 screws x 3/4"	3	\$0.20	\$0.60	2 needed, 1 extra, use these in the first mounting hole
30002	#10 screws x 1"	11	\$0.20	\$2.20	10 needed, 1 extra, use these in all other mounting holes
30003	Washers 5/16" x 7/8"	4	\$0.20	\$0.80	Use a minimum of 2. 3 recommended, 4th optional
30004	Cotter Pins 1/8" x 1" per Bag	1	\$2.99	\$2.99	6 pins per bag, use 2 and carry extras in your kit
	Assembly Charge	1	\$12.00	\$12.00	
	<b>Retail Price</b>			<b>\$93.59</b>	

This kit is intended for installing a WaterTribe Rudder on the stern of a Kruger Sea Wind or Dreamcatcher.

This kit may work on other types of kayak or canoe sterns as long as the stern is at least 6.5" long and more or less vertical.

The width of the stern should be more or less 2.5" wide measured roughly 5.25" back from the tip of the stern.

**IMPORTANT:** Installer will need to "form" the gudgeons to the stern using a wood block, hammer, and minimal force required.

Installer will need to buy 1 tube of 3M4200. Get the smallest tube available.

Gudgeon straps and mounting screws must be embedded in 3M4200 (recommended) or 3M5200 (OK, but permanent).

Be sure to read the installation instructions and view the installation DVD.

**NO GUARANTEE expressed or implied. Kit sold AS IS. NO REFUNDS FOR ANY REASON**